

When start interlock is active, the safety outputs of the RS4-4 (OSSD 1 and OSSD 2) will not be enabled or switched „active high“, even if the current detection zone is clear, until the RESTART button has been actuated for a period of 2 to 4 seconds (24 V to pin 2 of interface X1).

When startup test is active, after the scanner has been switched on, the safety outputs of the RS4-4 (OSSD1 and OSSD2) will not be enabled or switched „active high“, even if the current detection zone is clear, until the detection zone is temporarily violated one time.

When restart interlock is active, the safety outputs (OSSD 1 and OSSD 2) of the RS4-4 will not be enabled or switched „active high“, even if the current detection zone is clear, until the RESTART button has been actuated for a period of 2 to 4 seconds (24 V to pin 2 of interface X1). This function is active after every violation of the detection zone.

The **dust suppression function** of the ROTOSCAN RS4-4 is a software function for increasing the availability of the laser scanner in the presence of dirt or small particles in the air, such as insects. If dust suppression is activated, a somewhat larger addition to the detection zone contour must be made. With or without dust suppression, and with a detection zone radius of up to 3.5 m, the addition has a value of 81 mm. With activated dust suppression and a detection zone radius of 3.5 m or more, the addition has a value of 98 mm. The addition is shown in the echo data.

Please refer to Chapter 7 for information on defining detection zones when the dust algorithm is active.

Due to its four freely programmable field pairs, the ROTOSCAN RS4-4 can be used very flexibly in a wide range of applications. The selected detection zones are checked for plausibility when the admissible changeover sequence is chosen in the dialog „Admissible field pair changeovers“. Inadmissible changeover sequences are detected and cause the OSSDs to be switched off. Furthermore, each field pair can be defined as the system startup field pair.


These features are useful with automatic guided vehicles, for instance, when the detection zone is changed over to accommodate straight and curved routes and when the vehicle starts up in a straight section.

Function button
"Change configuration
data"

Path within RS4soft
(from left to right)

Matrix for determining
admissible field pair
changeovers


Matrix for determining
admissible startup
field pairs



After the scanner configuration has been entered, it must be transferred to the RS4; to do so, click on the function button „Transfer configuration data from PC to RS4“. If you forget to do this, the transfer dialog is automatically called up before another subject button can be selected. Due to the safe protocol, you can now view and confirm the echo data reflected by the scanner.



CAUTION! Since the PC is not a safety product and computer-specific errors can occur, the echo data transmitted by the RS4-4 must be checked for errors and confirmed by an authorized person.



If the echo data are returned accurately, you must confirm the record by pressing the button „Accept“. Changing a configuration can require that the detection zones be checked again. For information on the echo data, please refer to Chapter 7.13.

6.5.4 „Field pair 1 to 4" folders

Double-click on the folders to select the subfolders „detection zone“ and „warning field“. Selecting one of these subfolders causes field-specific data to appear in the right-hand section of the dialog box: name of the field, date and time of the latest change, field status, and information on admissible field pair changeovers. In addition, the minimum object width is stated with respect to the number of segments ($x * 0.36^\circ$). This means that the lateral value in millimeters is dependent upon the maximum radius of the field contour.

6.6 Set standard values for RS4, Function Button

This function allows you to reinstate the factory-set configuration (delivery state) of the ROTOSCAN RS4-4. As an alternative to this function button, you can also press the RESTART button (press pins 2 and 3 on connector X1) before switching on the scanner. Release the button after approx. 2 seconds; LEDs 2, 3 and 5 will be lit up in the scanner display. This means that the scanner has been reset. The table below describes the resultant setting:

Parameter	Value	Parameter	Value
Detection zone range	4 m	Application	Safeguarding an area
Detection zone display	190°	Restart	Manual
Detection zone re-response time	80 ms	Restart when reset	Activated restart interlock
Field pair changeover	No change-over	Startup type	None
Startup field pairs	1, 2, 3, 4	Dust algorithm	Activated
Detection zone name	- - -	Start segment output	0
Warning field range	5 m	Stop segment output	528
Warning field display	190°	Baud rate	57600 bd
Warning field, re-response time	80 ms	Name of the scanner	- - -
Alarm signaling type	Violation of the warning field	Description of the scanner	- - -

Please note that the reset function described above may not be repeated for a period of 2 minutes.



After determining the scanner configuration, the setting must be documented in suitable form at the monitored machine or system. You need to generate a text file of the configuration for this purpose.

The button „Generate text file“ allows you to do this. Clicking on this button initiates a dialog for entering the file name and converts the data into .txt format. To make a printout, open the file (e.g. „RS4-4.txt“) in a word processing program such as MS-Word® and click on the Print button.

The following information appears on the printout:

- Date, user, data source
- Scanner serial number, device type, software version
- Non-safety-critical parameters
- Safety-critical parameters
- Information on the detection zones and warning fields of all four field pairs



Read Chapter 9.1 to find out how to print out a detection zone contour.

7. Define detection zones/warning fields, Subject Button

This menu provides you with extensive possibilities for defining detection zones.

These include transferring data as well as creating and modifying the detection zones (for detecting the presence of personnel) and warning fields. Since this area involves safety-relevant functions of the scanner, access is possible only when the appropriate password is entered.



The smallest section of a detection zone must cover a lateral distance of at least 3.5 cm. When defining detection zones, make sure that no pin-shaped contours are set, as these do not provide a guaranteed safety effect.


The maximum selectable detection zone radii vary depending on the type of contour:

ROTOSCAN RS4-4	Range	Factory Setting
Detection zone	4 m	4 m
Warning field	15 m	5 m
Contour measurement	50 m	- - -

The scanner is factory-programmed with semicircular detection zones (190°) which will be in effect after the initial startup.



Please note that only detection zones (SF), and not warning fields (WF), may be used for the performance of safety-related tasks.



7.1 Load detection zone/warning field from file, Function Button

Click on this button to open a dialog box that will give you an overview of the field configurations already saved on the PC after you have entered the appropriate path and the file name. You can call up the desired configuration (file extension „.sf“) using the button „Open“ to make and confirm your selection. See Chapter 7.13 for information on transferring the data.

7.2 Save detection zone/warning field as a file, Function Button

Click on this button to open a dialog box that allows you to save the previously defined field configuration. Enter the path and the file name. Click on the button „Save“ to confirm your entry, and the configuration will be saved as an .sf file.

7.3 Select detection zone/warning field, Function Button

When you click on this drop-down menu, all eight fields (4 detection zones and 4 warning fields) will be displayed for you to select. Use the mouse to click on the field pair you want to define. The current contours of the detection zone and warning field will be shown in red and green, respectively. Unselected field pairs appear in gray/light gray.

7.4 Enter detection zone/warning field, Function Button

Click on this button to open a dialog box for numerically entering the dimensions of the detection zone/warning field in millimeters. You can enter dimensions for the front, left and right edges of the zone/field to be defined. Confirm the edge dimensions. These will then be displayed on the screen in the appropriate color (detection zone in red, warning field in green).

Please refer to the subpoint „190° field pairs“ in Chapter 9.2 .

7.5 Define elliptical detection zone/warning field, Function Button

When you click on this button, all of the tools except Zooming appear against a light gray background.

The program now waits for you to position the mouse pointer and set the coordinates for the elliptical contour. You can freely change the elliptical contour in the X- and Y-directions as long as you keep the right mouse button pressed within the contour field. The coordinate display is useful in helping you check the dimensions as you set them. When you have finished demarcating the field, release the right mouse button. The set mouse pointer marks the intersection of the horizontal and vertical line going to each side of the ellipsis. Equivalent sections of the field are always generated in the left and right halves of the display; these sections can be modified separately at a later point in time.

Please refer to the subpoint „190° field pairs“ (see Chapter 9.2).

7.6 Define rectangular detection zone/warning field, Function Button

When you click on this button, all of the tools except Zooming appear against a light gray background.

The program now waits for you to position the mouse pointer and set the coordinates for the rectangular contour. You can freely change the rectangular contour in the X- and Y-directions as long as you keep the right mouse button pressed within the contour field. The coordinate display is useful in helping you check the dimensions as you set them. When you have finished demarcating the field, release the right mouse button. The set mouse pointer marks the corner point of the horizontal and vertical line of the rectangle contour. Equivalent sections of the field are always generated in the left and right halves of the display; these sections can be modified separately at a later point in time.

Please refer to the subpoint „190° field pairs“ (see Chapter 9.2).

Detection zones and warning fields, 1 to 4 each

X-line/Y-line intersection - defined using the button "Define elliptical detection zone/warning field"

Defined using the button "Define rectangular detection zone/warning field"

Selection of five basic field contours

Distinguishing between the left and right field pair halves using a plus or minus sign

Field pair center line

Coordinates of the mouse pointer


A minus sign preceding the mouse pointer coordinates designates the left half of the field pair, or the area below the scanner zero axis.

7.7 Define polygonal detection zone/warning field, Function Button

When you click on this button, all of the tools except Zooming appear against a light gray background.

The program now waits for you to position the mouse pointer. Click on the right-hand mouse button to „draw“ the contour of the polygon point for point. The points along the contour are always entered clockwise from left to right. As long as the mouse button remains pressed within the contour field, you can freely shift the current line segment in the X- and Y-directions. The coordinate display is useful in helping you check the dimensions as you set them. Once you release the mouse button, the process is complete and the line is set. Beginning with the first point set by the mouse pointer, one line segment is added to the contour with every click of the mouse button. When the contour is complete, simply press the right-hand mouse button.

Please refer to the subpoint „190° detection zones“ (Chapter 9.2).




Button for activating the polygon function	e.g. 1st, 2nd, 3rd and 4th mouse click for the current field	Displayed deactivated detection zone and warning field (gray scale)	End point set by clicking the right mouse button	Measured contour
--	--	---	--	------------------

7.8 (freistehend)

7.9 Change detection zone/warning field segment, Function Button

Once a contour is specified, it can be modified by setting two coordinate points with respect to the beam axis. When you click on this button, all of the tools except Zooming appear against a light gray background. The program now waits for you to position the mouse pointer and click, thereby setting the coordinates for the two coordinate points. Use the coordinate display to check your selection. The section of the contour between the points is a line showing the connections to the previous contour. The connection itself follows the beam axis. After you have set the first corrective point, the program provides you with a yellow auxiliary line as a reference.



Limiting measures to be specified in the dialog

Button for activating the segment limitation

Limited contour


Sample contour for comparison

7.11 Blanking out a detection zone/warning field segment, Function Button

Once a contour is specified, you can blank out segments of the detection zone by setting two coordinate points. The segments between these two points will be blanked out. When you click on this button, all of the tools except Zooming appear against a light gray background.

The program now waits for you to position the mouse pointer and click, thereby setting the coordinates for the beginning and the end of the segment to be blanked out. The section of

the contour between the points is blanked out in the direction of the beam axis. After you have set the first corrective point, the program provides you with a yellow auxiliary line as a reference. The coordinate display is useful in helping you check your setting of the blanked out area.



- Button for activating the segment change
- Sample contour for comparison
- First and second coordinate point
- Auxiliary line (beam axis)
- Connective line following the beam axis



If you blank out sectors that can be entered or walked through, hazards to personnel can result if the minimum safety distance is no longer met. Additional measures must be taken to safeguard the danger zone in such cases.

7.12 Delete detection zone/warning field, Function Button

If you select this function, the detection zone definitions and warning field definitions are replaced by the factory settings (4 m radius for the detection zone, 5 m radius for the warning field).


7.13 Transfer detection zone/warning field from PC to RS4, Function Button

Click on this button to open a dialog box that gives an overview of the previously changed zone/field contours. This list allows you to select the zones/fields that you want to be transferred to the RS4-4.

Once the dialog has been confirmed, the loading/saving process begins and a progress bar appears on the screen. The ROTOSCAN RS4-4 sends the information it received back to the PC as echo data so that the data transfer can be verified. The transferred detection zone contours appear in a dialog; the contours must be checked and the dialog must be acknowledged accordingly. After the check sums have been recalculated, the transfer is concluded with an OK message.



CAUTION! Since the PC is not a safety product and computer-specific errors can occur, the echo data transmitted by the RS4-4 must be checked for errors and confirmed by an authorized person.



The echo data contain the detection zone contours, the maximum dimensions, the detection zone number, the date and time they were saved, the admissible detection zone changeovers, and the display of the detection zone addition. The latter point must first be considered by the user when defining the detection zones. For instructions on how to do this, refer to the Technical Description of the ROTOSCAN RS4-4.

After the detection zone definition has been completed, the configuration must be documented in a suitable form at the monitored machine or system. Please see Chapter 9.1.

8 RS4 system data, Subject Button

This menu allows you to call up device-specific identification data and special functions.

8.1 Load system data from the RS4, Function Button

Click on this function button to transfer device data with a logistical emphasis from the RS4-4 to the PC:

- Software version (Firmware)
- Designation, name
- Additional description
- Serial number
- Current authorization level

These data can also be archived as a text file on the PC.

8.2 Display RS4 error list, Function Button

This function button provides you with access to an RS4-4-internal ring memory in which the error messages of the eight most recent events are documented. The first position of the memory contains the most recent error message. In addition, you can see the sum of all the generated error messages. The information provided by this list enables you to draw very good conclusions as to possible causes of error. For an interpretation of the list of parameters, please refer to Chapter 16 in the Technical Description of the ROTOSCAN RS4-4.

8.3 Calibrate window monitoring, Function Button

It is necessary to perform a device-internal calibration of the window monitoring after the scanner window has been replaced, for instance.



Please note that only trained, expert personnel are allowed to replace and calibrate the exit window. This function can be accessed at the „Service“ authorization level (or higher) and requires the use of the security diskette. The password can be found in Chapter 3.3.

8.4 Reset RS4, Function Button

Click on this function button to send a reset command from the PC to the scanner. This function can be used, for instance, if there is no manual RESTART button and an error message was issued due to dirt buildup on the scanner window. Once the window has been cleaned and the error message has been reset, the scanner resumes its normal operation.

9 Additional Functions on the Main Menu Line

This chapter describes additional special functions that are not provided by the subject buttons.

9.1 Menu „View“

Function „Save diagram as a file“

Click on the subpoint „Save diagram as a file“ to open a dialog box for saving the displayed detection zone and warning field contours in .bmp format (bitmap). For documentation purposes, this screen shot can be called up using the program MS-Paint®, for instance, and supplemented with additional information. Enter the path and file name, and then confirm both in order to save the diagram as a file. During the storage process, a progress bar with a confirmation message appears on the screen.

9.2 Menu „Settings“

Subpoint „PC configuration“

Function „Interface“

Click on the subpoint „Interface“ to open a dialog box that allows you to set the parameters for the interface (comport) and the baud rate (data transfer speed).

Function „Language“

Click on the subpoint „Language“ to open a dialog box that allows you to select the language of the user interface and the program texts. The available languages are German, English, and French. Please note that a change in language will not take effect until the RS4soft program has been restarted.

Function „Change diagram color“

Click on the subpoint „Change diagram color“ to change the background color of the contour window from black to white (and vice versa).

This function makes the screen shots of the measurements more suitable for printing.

Function „190° detection zones and warning fields“

Click on the subpoint „190° detection zone/warning field“ to expand the definition of detection zones and warning fields by 10°. The registration of measurement values is not affected by this change.

Subpoint „Display messages“

Click on the subpoint „Display messages“ to open an information window showing a list of the operator steps performed since the software startup. The window can be maximized to allow for a better overview.

9.3 Menu „Detection zones/warning fields“

Function „Modified detection zones/warning fields“

Click on the subpoint „Modified detection zones/warning fields“ to open an information window showing all of the detection zones and warning fields that have been modified in the PC but have not yet been saved to the RS4-4. Each of these fields is identified by a marker. The markers remain in place until the detection zones and warning fields are saved to the RS4-4.

9.4 Menu „Security“

Function „Change password“

Click on the subpoint „Change password“ to open a dialog box for setting the access level (Maintenance [In] or Authorized customer [AK]). After making your selection, enter the password for the appropriate level. Confirm your entry by typing the password again in the second input field.

Please note that an access level of „Authorized customer (AK)“ is required in order to be able to change the passwords. The password must consist of at least six but no more than eight letters and/or digits. The characters being entered are concealed from view.



Please keep the password in a location that is inaccessible to unauthorized personnel.

Function „Reset password“

In the event that a password is lost, it is possible to define a new password. Use the subpoints „Reset password“ and „Generate one-shot password“ to create a security password that is shown in red. Fax or mail this password to Leuze lumiflex along with the complete address of your company, the user name, and the scanner serial number. You will immediately be sent a confirmed one-shot password which must be entered in the dialog „Setting new passwords“.

Once the new passwords have been entered in both fields, you can access the scanner on the „Authorized customer (AK)“ level.

If the confirmed one-shot password is entered incorrectly, the ROTOSCAN RS4-4 signals an error message at LED 5. In addition, an error message to that effect will appear on the screen after approx. 2 minutes. Please note that RS4soft is disabled during this time period and will not be able to process any new entries.

9.5 Menu „Help“

Function „Info“

The subpoint „Info“ shows the software version and the time at which the RS4soft software was created.

10 Additional Information and Summary

10.1 Initial Configuration

- Carefully study the guidelines and standards that are valid for your application. (Consult Chapter 2.4 of the RS4-4 Technical Description.)
- Read the RS4soft User Manual and the Technical Description of the ROTOSCAN RS4-4 thoroughly.
- Start your PC with all required peripheral devices – but without the scanner connection.
- Install RS4soft.
- When unpacking the ROTOSCAN RS4-4, avoid touching the exit window and the diffusing screens.
- Plug in the ROTOSCAN RS4-4 using connector X1 as described in the instructions.
- Connect the ROTOSCAN RS4-4 to the PC using connector X2 as described in the instructions.
- Once the operating voltage is applied, the scanner signals communication readiness after approx. 20 s. You can see this state when the message „RS4 connect“ appears on the screen.
- The ROTOSCAN RS4-4 is delivered with factory-set standard parameters programmed for the maximum detection zone size.
- As a result of the factory setting, each field pair consists of a detection zone and a warning field with exactly the same dimensions, making them appear as a single contour. It is always a field pair that is activated.
- Since restart interlock is activated, it is not possible to enable the OSSDs until 24 V is applied at pin 2 of connector X1. Please note the supply voltage specifications in the Technical Description of the ROTOSCAN RS4-4, Chapter 4.2.

- Please be aware of detection zone violations which may occur due to the maximum selected size of the detection zone.
- Please document the scanner configuration as specified in Chapter 6.6.

10.2 Changing a Scanner Configuration or Field Definition

- Faultless data communication must be established before any changes can be made. This state is signaled on the screen by the message „RS4 connect“.
- In order to make changes, you must have access to the authorization level „Authorized customer“.
- Changes are only possible if a configuration has been loaded onto the PC. You can load a configuration either from the hard drive or from the ROTOSCAN RS4-4.
- Changes to a configuration are not accepted by RS4soft until you confirm them by pressing the buttons „Accept“ or „OK“.
- Changes do not take effect until the data has been successfully transferred to the scanner.
- If detection zones are loaded as a file from the hard drive, for instance, you must verify the plausibility of the scanner configuration.
- Please consider the necessary safety distance and the required additions to the detection zone.
- You must comply with the safety precautions described in the RS4soft User Manual and in the Technical Description of ROTOSCAN RS4-4.
- Please document the scanner configuration as specified in Chapter 6.6.

10.3 Creating a Configuration Without a Connected Scanner

- After calling up RS4soft, select the authorization level „Authorized customer“.
- The initial display of the measurement field does not show any field contours.
- Enter the password for the appropriate user level.
- You can use the subject button „RS4 configuration“ to load a configuration file from the hard drive onto the PC. The file extension is „.rs“.
- Note that configuration files contain scanner configurations as well as field definitions.
- You can use the subject button „Define detection zones/warning fields“ to load a field file from the hard drive onto the PC. The file extension is „.sf“.
- Please note that field files do not contain any scanner configurations.
- Saved files can be loaded onto the ROTOSCAN RS4-4.

10.4 Replacing Devices

- After a replacement scanner has been connected to the PC, load the configuration data first. The status information will then be displayed on the screen so that it can be verified.
- Identical configurations can be identified by the output of the date and time when the field was saved, among others.
- If the scanner is new, you can program it more quickly by transferring the previous configuration file, as long as this still corresponds to the requirements of the application.
- When replacing a device, make sure that the scanner parameters and the complete detection zone definitions are transferred correctly.

- Compare the data of the previous scanner with the echo data of the new scanner.
- Comply with the safety precautions in the Technical Description of the ROTOSCAN RS4-4.
- Please document the scanner configuration as specified in Chapter 6.6.

Sales and Service

A Austria

Ing. Franz Schmachtl KG
Postfach 362, A-4021 Linz/Donau
Tel. Int. + 43 (0) 732/76 46-0
Fax Int. + 43 (0) 732/78 50 36
E-mail: office.linz@schmachtl.at
<http://www.schmachtl.at>

ARG Argentina

Nortécnica S.R.L.
103-ex Heredia 638
1672 Villa Lynch – Pcia. de
Buenos Aires, Argentinien
Tel. Int. + 54 (0) 11/47 57-3129
Fax Int. + 54 (0) 11/47 57-1088
E-mail:
awigutow@nortecnica.com.ar

AUS + **NZ**

Australia + New Zealand

Balluff-Leuze Pty. Ltd.
2 Rocco Drive
AUS-Scoresby VIC 3179
Melbourne, Australia
Tel. Int. + 61 (0) 3/97 64 23 66
Fax Int. + 61 (0) 3/97 53 32 62
E-mail: balluff_leuze@
matcol.com.au

B Belgium

Leuze electronic nv / sa
Steenweg Buda 50
B-1830 Machelen
Tel. Int. + 32 (0) 2/253 16 00
Fax Int. + 32 (0) 2/253 15 36
E-mail: Leuze.info@leuze.be

BR Brazil

Leuze electronic Ltda.
Av. Juruá, 150-Alphaville
BR-06455-010 Barueri - S. P.
Tel. Int. + 55 (0) 11/41 95 61 34
Fax Int. + 55 (0) 11/41 95 61 77
E-mail: leuze@leuze.com.br
[originet.com.br](http://www.leuze.com.br)

CH Switzerland

Leuze electronic AG
Ruchstuckstrasse 25
CH-8306 Brüttisellen
Tel. Int. + 41 (0) 1/834 02 04
Fax Int. + 41 (0) 1/833 26 26
E-mail: leuze@leuze.ch
<http://www.leuze.de>

CO Columbia

Componentes Electronicas Ltda.
P.O. Box 478, CO-Medellin
Tel. Int. + 57 (0) 4/351 10 49
Fax Int. + 57 (0) 4/351 10 19
E-mail:
rigogigu@col3.telecom.com.co

CZ Czech Republic

Schmachtl CZ spol. s.r.o.
Videnská 185
CZ-25242 Vestec u. Praha
Tel. Int. + 420 (0) 2/44 00 15 00
Fax Int. + 420 (0) 2/44 91 07 00
E-mail: office@schmachtl.cz
<http://www.schmachtl.cz>

D Germany

Lindner electronic GmbH
Schulener Landstr. 128
D-30165 Hannover
Tel. Int. + 49 (0) 511/96 60 57-0
Fax Int. + 49 (0) 511/96 60 57-57
E-mail: lindner@leuze.de
W+M Plantechnik
Dipl.-Ing. Wörtler GmbH + Co.
Tannenbergsstraße 62
D-42103 Wuppertal
Tel. Int. + 49 (0) 202/371 12-0
Fax Int. + 49 (0) 202/31 84 95
E-mail: wmplan@rga-net.de
Leuze electronic GmbH + Co.
Geschäftsstelle Owen
In der Braike 1
D-73277 Owen / Teck
Tel. Int. + 49 (0) 70 21/98 50-910
Fax Int. + 49 (0) 70 21/98 50-911
E-mail: vgo@leuze.de

Leuze electronic GmbH + Co.
Geschäftsstelle Dresden
Niedersiedlitzer Straße 60
D-01257 Dresden
Tel. Int. + 49 (0) 351/284 11 05
Fax Int. + 49 (0) 351/284 11 03
E-mail: vgd@leuze.de

Leuze electronic GmbH + Co.
Geschäftsstelle Frankfurt
Moselstraße 50
D-63452 Hanau
Tel. Int. + 49 (0) 6181/91 77-0
Fax Int. + 49 (0) 6181/91 77 15
E-mail: vgf@leuze.de

Leuze electronic GmbH + Co.
Geschäftsstelle München
Ehrenbreitsteiner Straße 44
D-80993 München
Tel. Int. + 49 (0) 89/143 65-200
Fax Int. + 49 (0) 89/143 65-220
E-mail: vgm@leuze.de

DK Denmark

Jokab Safety DK A/S
Rugmarken 15.1
DK-3520 Farum
Tel. Int. + 45 (0) 44 34 14 54
Fax Int. + 45 (0) 44 99 14 54
<http://www.leuze.de>

E Spain

Leuze electronic S.A.
C/ Joan Güell, 32
E-08028 Barcelona
Tel. Int. + 93(0) 409 79 00
Fax Int. + 93(0) 490 35 15
E-mail: leuze@chi.es
<http://www.leuze.de>

F France

Leuze electronic sarl.
Z.I. Nord Torcy, B.P. 62-BAT 3
F-77202 Marne la Vallée Cedex 1
Tel. Int. + 33 (0) 160 05 12 20
Fax Int. + 33 (0) 160 05 03 65
E-mail: infos@leuze-electronic.fr
<http://www.leuze-electronic.fr>

FIN Finland

SKS-teknikka Oy
P.O. Box 122, FIN-01721 Vantaa
Tel. Int. + 358 (0) 9/85 26 61
Fax Int. + 358 (0) 9/852 68 20
E-mail: sks-teknikka@sksf.fi
<http://www.sks.fi>

GB Great Britain

Leuze Mayser electronic Ltd.
Generation Business Park
Barford Rd
GB-St. Neots, Cambs, PE19 6YQ
Tel. Int. + 44 (0) 1480/40 85 00
Fax Int. + 44 (0) 1480/40 38 08
E-mail: mail@leuzemayser.co.uk
<http://www.leuzemayser.co.uk>

GR Greece

UTECO A.B.E.E.
5, Mavrogenous Str.
GR-18542 Piraeus
Tel. Int. + 30 (0) 1/421 00 50
Fax Int. + 30 (0) 1/421 20 33
E-mail: uteco@uteco.gr
<http://www.leuze.de>

H Hungary

Kvalix Automatika Kft.
Pf. 83, H-1327 Budapest
Tel. Int. +36 (0) 1/399 06 15
Fax Int. +36 (0) 1/369 84 88
E-mail: info@kvalix.hu
<http://www.kvalix.hu>

HK Hong Kong

Sensortech Company
No. 43, 18th Street
Hong Lok Yuen
Tai Po N.T. Hongkong
Tel. Int. + 852/26 51 01 88
Fax Int. + 852/26 51 03 88
E-mail: sensortech@attglobal.net

I Italy

I/O Leuze Vogtle Malanca s.r.l.
Via Soperga 54, I-20127 Milano
Tel. Int. + 39 02/284 04 93
Fax Int. + 39 02/26 11 06 40
E-mail: ivoleuze@tin.it
<http://www.leuze.de>

IL Israel

Galoz electronics Ltd.
P.O. Box 35
IL-40850 Rosh Ha'ayin
Tel. Int. + 972 (0) 3/902 34 56
Fax Int. + 972 (0) 3/902 19 90

IND India

Global Tech Corp.
403, White House, 1482, Sadashir
Peth, Tilak Road
Pune - 411030, India
Tel. Int. +91 (0) 2 12/47 00 85
Fax Int. +91 (0) 2 12/47 00 86
E-mail:
globtech@giaspn01.vsnl.net.in

J Japan

Riken Optech Corporation
2 - 6 - 9 Higashi Oh
Shinagawa-Ku
Tokyo 140-8533 Japan
Tel. Int. +81-3-3474-86 02
Fax Int. +81-3-3450-52 95

MAL Malaysia

Ingermark (M) SDN.BHD
No. 29 Jalan KPK 1/8
Kawasan Perindustrian Kundang
MAL-48020 Rawang,
Selangor Darul Ehsan
Tel. Int. + 60 (0) 3/60 34 27 88
Fax Int. + 60 (0) 3/60 34 21 88
E-mail: ingmal@tm.net.my

N Norway

Automasjon og Sikkerhet
Skolhusveien 25
N-1433 Vinterbro
Tel. Int. + 47/64 94 58 60
Fax Int. + 47/64 94 61 60

NL The Netherlands

Leuze electronic B.V.
Postbus 1276
NL-3430 BG Nieuwegein
Tel. Int. + 31 (0) 30/606 63 00
Fax Int. + 31 (0) 30/606 09 70
E-mail: info@leuze.nl
<http://www.leuze.nl>

P Portugal

LA2P, Lda.
Rua Teófilo Braga 156 A-F
Edif. S. Domingos Cabeco do Mouro
P-2785 - 122 S. Dom. de Rana
Tel. Int. +351 21/444 70 70
Fax Int. +351 21/444 70 75
E-mail: la2p@ip.pt
<http://www.la2p.pt>

PL Poland

Balluff Sp.z o.o.
ul. Powsinska 106
PL-02-903 Warszawa
Tel. Int. + 48 (0) 22/ 651 96 79
Fax Int. + 48 (0) 22/ 842 97 28
E-mail: balluff@balluff.pl
<http://www.leuze.de>

RCH Chile

Imp. Tec. Vignola S.A.I.C.
Plaza Justicia, Sub El Peral 25
Casilla 93-V, RCH-Valparaiso
Tel. Int. + 56 (0) 32/25 65 21
Fax Int. + 56 (0) 32/25 85 71
E-mail: vignoval@entelchile.net

ROC Taiwan

Great Cofue Technology Co. Ltd.
4F-8, 39, Sec. 4, Chung Hsin Road
San-Chung City
Taipei Hsien, Taiwan R.O.C.
Tel. Int. + 886 (0) 2/29 83 80 77
Fax Int. + 886 (0) 2/29 85 33 73
E-mail: gcofue@mail.eranet.net

ROK South Korea

Useong Electrade Co.
No 3325, Gadong, Chungang, Civr.
No 1258, Guro-Bondong, Guroku
Seoul, Korea
Tel. Int. + 82 (0) 2/6 86 73 14/5
Fax Int. + 82 (0) 2/6 86 73 16
E-Mail: haegon97@unitel.co.kr
<http://www.leuze.co.kr>

RP Philippines

JMTI Industrial Corporation
No. 5, Saturn Street
Bricktown, Moonwalk
Paranaque
Metro Manila, Philippines
Tel. Int. + 63 (0) 2/844 63 26
Fax Int. + 63 (0) 2/893 22 02

RSA South Africa

Countpulse Controls (PTY.) Ltd.
P.O.Box 40393
RSA-Cleveland 2022
Tel. Int. + 27 (0) 11/615 75 56-8
Fax Int. + 27 (0) 11/615 75 13

S Sweden

Jokab Safety A/S
Boplatsgatan 3, S-21376 Malmö
Tel. Int. + 46 (0) 40/14 36 30
Fax Int. + 46 (0) 40/22 92 88
E-mail: info@jokabsafety.se
<http://www.jokabsafety.se>

SGP Singapore

Balluff Asia Pte Ltd
Blk 1004, Toa Payoh,
Industrial Parc, Lorong 8 #03-1489
Singapore 319076
Tel. Int. + 65/252 43 84
Fax Int. + 65/252 90 60
E-mail: balluff@balluff.com.sg

SK Slovak Republic

SCHMACHTL SK s.r.o.
Bardosova 2/A, SK-83309 Bratislava
Tel. Int. + 421 (0) 7/54 77 74 84
Fax Int. + 421 (0) 7/54 77 74 91
E-mail: office@schmachtl.sk
<http://www.schmachtl.sk>

SLO Slovenia

Tipteh d.o.o.
Cesta v Gorice 40
SLO-1111 Ljubljana
Tel. Int. + 386 (0) 61/200 51 50
Fax Int. + 386 (0) 61/200 51 51
E-mail: info@tipteh.si
<http://www.Tipteh.si>

T Thailand

Industrial Electrical Co. Ltd.
85/2, 85/3 Soi Sot Phin San
Rang Nam Road, Rajthevee
T-10400 Bangkok - Thailand
Tel. Int. + 66 (0) 2/642 67 00
Fax Int. + 66 (0) 2/642 42 50

TR Turkey

MEGA Teknik elek. San. ve Tic. Ltd.
Perpa Ticaret Is Merkezi
A Blok Kat 2 No: 9/0026 80270
TR-80270 Okmeydani Istanbul
Tel. Int. + 90 (0) 212/320 04 11
Fax Int. + 90 (0) 212/320 04 16
E-mail: mega@netone.com.tr
<http://www.leuze.de>

USA + CDN + MEX

**United States +
Canada + Mexico**
Leuze Lumiflex Inc.
300 Roundhill Drive, Unit 4
USA-Rockaway, NJ 07866
Tel. Int. + 1 (0) 973/586-0100
Fax Int. + 1 (0) 973/586-3230
E-mail: info@leuze-lumiflex.com
<http://www.leuze-lumiflex.com>

Leuze lumiflex

Leuze lumiflex GmbH + Co.
Ehrenbreitsteiner Str. 44
D-80993 München
Tel. + 49 (0) 89 / 1 43 65-0
Fax + 49 (0) 89 / 1 43 65-190
e-mail: lumiflex@leuze.de
<http://www.leuze.de>